

CHANGING THE CARBON FILTER CUP

The coconut shell carbon filter cup helps remove any remaining taste and/or odor from the distilled water. The filter cup should be replaced every two months or 60-80 gallons of water processed (whichever comes first). Replace more often should the distilled water begin to have an unwanted taste or odor.

Sterilize & Rinse

Remove and discard used filter cup. Before installing new filter cup, remove and discard the two protective seals (one on top & one on bottom). Pour one to two cups of DISTILLED water through the filter cup to rinse away any small harmless carbon fines (dust). Water draining from the filter cup could contain black dust. This is typical. This carbon dust is formed as a result of production, packaging and shipping of the filter cup. Once water runs clear through the filter cup, to ensure optimum water purity, it is recommended that each new filter cup be properly sterilized by fully immersing in boiling water for about five minutes. Allow filter cup to cool before handling. Rinse briefly with pure water before installing.

Install

There is a label packaged with each filter cup. Write in the date of installation as a replacement reminder. Place the sterilized filter cup into opening of collection/storage container.

Replace

Discard used filter cup and replace it every two months or after 60-80 gallons of water processed (whichever comes first). DO NOT attempt to reuse filter cups.

